

DPE

DARK PERFORMANCE ENGINEERING

KIMMO

Immobilizer bypass unit for K and D series ECUs: PRB, PRA, PND, PLM, PLR, PNF, PPA



Thank you for purchasing Kimmo, DPE immobilizer bypass and multiplexor error disable unit.

You'll need to connect 4 wires to get it working:

Black wire: Ground. Connect to ECU connector A pin 4.

Yellow Wire: Ignition switched power. Connect to ECU connector A pin 2.

Red Wire: Immobilizer bypass. Cut the wire that goes to pin 27 on connector E and replace it with the Kimmo unit red wire.

Please note: If you're using a 01-05 Civic or 02-04 RSX chassis do not connect the next wire.

Blue wire: Multiplexor. Cut the wire that goes to pin 24 on E connector and replace it with the kimmo unit blue wire.

